If you are using a printed copy of this procedure, and not the on-screen version, then you <u>MUST</u> make sure the dates at the bottom of the printed copy and the on-screen version match.

The on-screen version of the Collider-Accelerator Department Procedure is the Official Version.

Hard copies of all signed, official, C-A Operating Procedures are kept on file in the C-A ESHQ

Training Office, Bldg. 911A.

ard copies of all si		rating Procedures are kep Office, Bldg. 911A.	ot on file in the C-A ESHQ
	C-A OPERATIONS	PROCEDURES MANU	UAL
	7.1.50 Purge of V	Varm Expander Inlet Filt	ter
	Text Pa	nges 2 through 5	
	Hand Pr	ocessed Changes	
HPC No.	<u>Date</u>	Page Nos.	<u>Initials</u>
		Signature on File	
	Collid	er-Accelerator Departme	ent Chairman Dat

D. Lederle

7.1.50 Purge of Warm Expander Inlet Filter

1. Purpose

To provide instruction for purging the warm expander inlet filters to remove air and moisture from the filters.

2. Responsibilities

- 2.1 The Shift Supervisor or an operator designated by the Shift Supervisor is responsible for conducting the procedure and providing documentation in the cryogenic control room log.
- 2.2 Should a problem arise in the process of purging an expander, the shift supervisor shall report to the technical supervisor for instructions before continuing.

3. Prerequisites

- 3.1 The filter must be offline while purging.
- 3.2 The pure helium supply line must be pressurized.

4. Precautions

If there is liquid in the refrigerator pots, all personnel entering the refrigerator wing of Bldg. 1005R must be ODH Class 1 qualified, have a Personal Oxygen Monitor (POM) and carry an emergency escape pack.

5. Procedure

5.1	Purge	"A" train filter FA1 as follows:
	5.1.1	Ensure filter isolation valves H9136M and H9139M are closed.
	5.1.2	Ensure closed filter purge valve H9141M.
	5.1.3	Align pure helium supply by closing valves H6181M, H9118M and H9119M Open valve H417M
	5.1.4	Connect flex line to valve H9119M.
	5.1.5	Purge flex line and connect to filter valve H9141M.

	5.1.6	Open valves H9119M, H9140M, H9137M and H9138M
	5.1.7	Throttle valve H9141M to produce an audible purge.
	5.1.8	When vent piping is approximately ambient temperature, stop the purge by closing valves H9138M, H9141M, H9140M and H9137M
	5.1.9	Close valve H9119M.
	5.1.10	Vent flex line through valve H6181M and disconnect.
	5.1.11	Open filter outlet valve H9139M as a sign that filter FA1 is ready for service.
5.2	Purge '	"A" train FA2 filter as follows:
	5.2.1	Ensure filter isolation valves H9144M and H9146M are closed
	5.2.2	Ensure filter purge valve H9147M is closed.
	5.2.3	Align pure helium supply by closing valves H6181M, H9118M and H919M Open valve H417M
	5.2.4	Connect flex line to valve H9119M.
	5.2.5	Purge flex line and connect to filter valve H9147M.
	5.2.6	Open valves H9119M, H6168M, H6167M and H9145M
	5.2.7	Throttle valve H9147M to produce an audible purge.
	5.2.8	When vent piping is approximately ambient temperature, stop the purge by closing valves H9145M, H9147M, H6168M and H6167M
	5.2.9	Close valve H9119M.
	5.2.10	Vent flex line through valve H6181M and disconnect.
	5.2.11	Open filter outlet valve H9146M as a sign that filter FA2 is ready for service.

5.3	Purge	"B" train filter FB1 as follows:
	5.3.1	Ensure filter isolation valves H9122M and H9125M are closed.
	5.3.2	Ensure filter purge valve H9127M is closed.
	5.3.3	Align pure helium supply by closing valves H6181M, H9118M and H919M Open valve H417M
	5.3.4	Connect flex line to valve H9119M.
	5.3.5	Purge flex line and connect to filter valve H9127M.
	5.3.6	Open valves H9119M, H9126M, H9123M and H9124M
	5.3.7	Throttle valve H9127M to produce an audible purge.
	5.3.8	When vent piping is approximately ambient temperature, stop the purge by closing valves H9124M, H9127M, H9126M and H9123M
	5.3.9	Close valve H9119M.
	5.3.10	Vent flex line through valve H6181M and disconnect.
	5.3.11	Open filter outlet valve H9125M as a sign that filter FB1 is ready for service.
5.4	Purge	"B" train filter FB2 as follows:
	5.4.1	Ensure filter isolation valves H9130M and H9132M are closed.
	5.4.2	Ensure filter purge valve H9133M is closed.
	5.4.3	Align pure helium supply by closing valves H6181M, H9118M and H919M Open valve H417M
	5.4.4	Connect flex line to valve H9119M.
	5.4.5	Purge flex line and connect to filter valve H9131M.
	5.4.6	Open valves H9119M, H6166M, H6165M and H9131M
	5.4.7	Throttle valve H9133M to produce an audible purge.

		5.4.8 When vent piping is approximately ambient temperature, stop the purge by closing valves H9131M, H9133M, H6166M and H6165M	
		5.4.9 Close valve H9119M.	
		5.4.10 Vent flex line through valve H6181M and disconnect.	
		5.4.11 Open filter outlet valve H9132M as a sign that filter FB2 is ready for service.	
6.	Docum	<u>Documentation</u>	
	6.1	The check off lines on the procedure are for place keeping only. The procedure is not to be initialed or signed, it is not a record.	
	6.2	The Shift Supervisor, or designee, shall document the completion of the procedure in the cryogenics control room log.	
7.	Refere	<u>rences</u>	
	7.1	Drawing 3A995009, 25 kw Helium Refrigerator P&ID	
8.	<u>Attacl</u>	<u>chments</u>	
	None		